



# INSTALLATION MANUAL




## TOOLS REQUIRED




PENCIL




( $\varnothing 6$ ;  $\varnothing 3.2$ ) DRILL BIT



SILICONE & GUN




FLAT AND CROSS  
HEAD SCREWDRIVERS




TAPE MEASURE



SPIRIT LEVEL
























ELECTRIC DRILL











RUBBER HAMMER


## PACKING LIST

 <b>A</b> X1	 <b>B</b> X1	 <b>D</b> X1	 <b>E</b> X1	 <b>F</b> X1	 <b>G</b> X1	 <b>H</b> X1
 <b>I</b> X2	 <b>J</b> X1	 <b>K</b> X1	 <b>L</b> X2	 <b>M</b> X5	 <b>N</b> X5	 <b>P</b> X2
 <b>T</b> X2	 <b>R</b> X1	 <b>S</b> X1	 <b>X</b> X2	 <b>Y</b> X1	 <b>Z1</b> X1	 <b>Z2</b> X1


The following components are packed in another products which would be matched with this product.

 <b>C</b> X1	 <b>U</b> X1	 <b>V</b> X4	 <b>W</b> X4	 <b>M2</b> X4	 <b>N2</b> X4	 <b>O</b> X4
						 <b>Q</b> X1

PRODUCT SCHEMATIC DIAGRAM




1




Please make sure that the corner protectors are left until after the item has been installed, this protects the glass from any breakage

2




3




(3)


4




5



6




7




(4)


8




9





10



(5)







12










13




14



(8)





16




Apply some silicone on the outside edge of the shower enclosure (between the wall profiles and wall and between the frame and the tray) to enhance waterproof. After installation, it needs 24hours for silicone to dry before being put into use.

## A. DOUBLE OUTWARD DOORS



Z2



Apply some silicone on the outside edge of the shower enclosure (between the wall profiles and wall and between the frame and the tray) to enhance waterproof. After installation, it needs 24hours for silicone to dry before being put into use.

## **Cleaning & Maintenance**

*Clean the small components regularly to prevent the drain from being jammed.usually, clean the shower enclosure by mop with mild detergent.*

*Don't clean the shower enclosure with irritant detergent,such as alcohol, gasoline or other chemical cleaner.*

*Should there be any dirty stains on the shower enclosure,you may clean it by woven cloth with toothpaste,but you need to clean it with water afterwards.*

*After the installation is completed, if you find there is much noise when the glass door moves,you may add small quantity of lubricant onto the roller wheel,slipping hook and the track.*