


INSTALLATION MANUAL




TOOLS REQUIRED




PENCIL




($\varnothing 6$, $\varnothing 3$, 2) DRILL BIT



SILICONE & GUN



FLAT AND CROSS
HEAD SCREWDRIVERS




TAPE MEASURE



SPIRIT LEVEL
























ELECTRIC DRILL


















RUBBER HAMMER




LIST OF SPARE PARTS

 X1	 X1	 X1	 X1	 X2	 X1	 X1
A	B	C	D	E	F	G
 X1	 X2	 X2	 X1	 X2	 X4	 X1
H	I	J	K	L	V	N
 X1	 X1	 X2	 X6	 X4	 X2	 X2
O	P	Q	R	S	W	X


The following components are packed in another products which would be matched with this product.

 X1	 X1	 X2	 X1	 X2	 X1	 X1
a	b	c	d	e	f	g
 X1	 X4	 X2	 X4	 X1	 X1	 X1
h	j	k	l	m	n	o
 X4						
q						


PRODUCT SCHEMATIC DIAGRAM



1




2




10mm gap from the edge of wall profile to the outside edge of the tray, which make sure enough room for fitting the glass fixing clamp

(3)




3



4




5




(4)

6





7




(5)

8




9




(6)



10





11



12




13




(8)


14



15




16




Apply some silicone on the outside edge of the shower enclosure (between the wall profiles and wall and between the frame and the tray) to enhance waterproof. After installation, it needs 24 hours for silicone to dry before being put into use.

MATCH WITH SIDE PANEL



a





(10)




b




c




d



e





Apply some silicone on the outside edge of the shower enclosure (between the wall profiles and wall and between the frame and the tray) to enhance waterproof. After installation, it needs 24hours for silicone to dry before being put into use.

Cleaning & Maintenance

Clean the small components regularly to prevent the drain from being jammed. usually, clean the shower enclosure by mop with mild detergent.

Don't clean the shower enclosure with irritant detergent, such as alcohol, gasoline or other chemical cleaner.

Should there be any dirty stains on the shower enclosure, you may clean it by woven cloth with toothpaste, but you need to clean it with water afterwards.

After the installation is completed, if you find there is much noise when the glass door moves, you may add small quantity of lubricant onto the roller wheel, slipping hook and the track.